

# Popcorn

## Operating Machine

Turn on "MASTER" switch and the interior lamp will come on the warming element in the base will be activated.

Turn on "KETTLE" switch and the heat to the kettle and the agitating motor will activate.

Wait approximately 5 minutes to allow the kettle to get up to operating temperature.

Cut open premeasured popcorn package and pour butter and kettle corn inside at one time.

Allow the corn to pop until the popping ceases (3 seconds between pops) the dump the kettle by turning the handle clock-wise and pulling downward.

For additional batches repeat above steps.

After popping final batch, turn off the "kettle" switch and with a damp cloth wipe any excess oil from inside and outside of the kettle to prevent burning.

**USE CAUTION as the Kettle will be HOT!**

If you leave the "Master" switch in the on position the warming element in the base will keep any popped corn fresh and warm.

*Action Event & Party Rentals*

559-583-6100